



- NOTES:
1. All wiring should be tin/copper 22 AWG unless noted otherwise.
  2. DO NOT run vestibule spkr. wire in the same cable as the apt. signal & common wires.
  3. Run all intercom wires separately from AC wires.
  4. For DC door release operation, connect door release to L+ and L-.
  5. For 16 VAC door release, use transformer model TR1.

		TITLE: AF-3600 WIRING DIAGRAM		
		DWG NO. - 254180		
		USED ON: MULTIPLE ENTR. SYSTEMS		
		DRN:TM	CHK:KN	DATE:05/27/2002