

5025 Jeron Amplifier	AF1000 Amplifier
AC	AC1
AC/DS	AC2
DS	DO
	L+
	L-
C	C
	PT
L	PT(4 Wire)
	T
See Note 2	T(3 Wire)
D	D
LC	SC
LL	S
See Note 1	PDR
	B
SC	BW (warble tone)

Note 1: Connect postal lock switch to terminals C and D

Note 2: When replacing a Jeron amp, a 10 micro farad capacitor must be installed between PT(4W) and T(3W)

