


<u>FMC-10 Amplifier</u>	<u>AF1000 Amplifier</u>
AC	AC1
AC/A	AC2
B	DO
	L+
	L-
C (apartment common)	C
3	PT
	PT(4 Wire)
2	T
	T(3 Wire)
1	D
C (vestibule speaker)	SC
S	S
PDR	PDR
	B
P	BW (warble tone)



**Note: On the FMC-10 amplifier the C (Common) terminal is connected to Apartment wire C and one side of the entry panel speaker. The apartment common C and the entry panel speaker must be connected independently to the AF1000 amplifier.**